

White Lace Inn

Southern Biscuit Muffins

Ingredients:

2 1/2 cups all purpose flour
1/4 cup sugar
1 1/2 tablespoons baking powder
3/4 cup cold butter
1 cup buttermilk

Directions:

Preheat oven to 400°.
Grease 12 (2 1/2 -inch) muffin cups or use muffin liners In large bowl, combine dry ingredients. Cut in butter until mixture resembles coarse crumbs. Stir in milk just until mixture is moistened. Spoon into muffin cups. Bake 20 minutes or until golden. Remove from pan. Cool on wire rack.

White Lace Inn • 16 N 5th Ave. Sturgeon Bay, WI 54235
(920) 743-1105 • www.WhiteLaceInn.com • Door County, Wisconsin